


Folding Instructions for MountainBike



DISC BRAKE

Slide the Guard behind the disc brake and fold the side flaps to the middle.

Fold the Guard over the disc brake and insert the pre-folded end from the opposite side between the Guard and the disc brake.




GEAR CLUSTER

Slide the Guard behind the gear cluster and fold the side flaps to the center.

First fold the side with the circular cut-out over the gear cluster, then repeat with the opposite side.

Use the closing mechanism to secure the Guard.






Folding Instructions for MountainBike



CRANK






- Turn bike upside down.
- Place the Guard over the right pedal and move it towards the center.
- Fold Guard over the crank and the opposite pedal. Move pedal into a horizontal position.
- Insert the side flap between frame and crank and secure with the Velcro strap.



DERAILLEUR

Folding Instructions

- Turn bike upside down.
- Feed the skewer through Guard. Round flap facing forward.
- Choose the right gear and place the chain over the Guard ring.
- Fold the sides in and secure with Velcro strap.
- Fold the top and bottom flaps inwards and click in place.



Folding Instructions for MountainBike



FRONT SHOCK

- Turn bike upside down.
- Fold opposite sides of Guard inwards and interlock.
- Insert the end pieces into the precut holes
- Feed the skewer through the Guard and secure

